

DB37-JST-245 Cable

RADIO PORT

- 1
- 20
- 2
- 21
- 3
- 22
- 4
- 23
- 5
- 24
- 6
- 25
- 7
- 26
- 8
- 27
- 9
- 28
- 10
- 29
- 11
- 30
- 12
- 31
- 13
- 32
- 14
- 33
- 15
- 34
- 16
- 35
- 17
- 36
- 18
- 37
- 19

GND

- +13.8V
- RS232 RTS
- RS232 CTS
- RSTTL OUT
- FILTER OUT
- CI-V IN
- RS232 IN
- RS232 OUT
- FILTER IN
- PTT1 OUT
- PTT2 OUT
- CW OUT
- GND


JRC-JST245

- RS-232 TX
- RS-232 RX
- PTT2
- CW

- GND
- +13.8V
- TRX Audio IN
- PTT2
- TRX Audio OUT
- CW
- RS-232 TX
- RS-232 RX
- TRX Audio IN
- TRX Audio OUT

- 1
- 14
- 2
- 15
- 3
- 16
- 4
- 17
- 5
- 18
- 6
- 19
- 7
- 20
- 8
- 21
- 9
- 22
- 10
- 23
- 11
- 24
- 12
- 25
- 13


ACC
DB25M



RADIO KEY
STEREO 6.3mm (1/4")

- 1
- 14
- 2
- 15
- 3
- 16
- 4
- 17
- 5
- 18
- 6
- 19
- 7
- 20
- 8
- 21
- 9
- 22
- 10
- 23
- 11
- 24
- 12
- 25
- 13

RS232
DB25M



MIC
FOSTER 8