


DB37-TS-6 Cable



TS-140 TS-440 TS-450 TS-680 TS-690 TS-711 TS-790 TS-811 TS-850 TS-940 TS-950

Notes:

- * FSK RCA is necessary only for the TS-850 TS-950
- ** PTT2 mutes front MIC

S = Sleeve
T = Tip
R = Ring

TS140 , TS680 - requires Kenwood IF-10C
 TS711 , TS811 - requires Kenwood IF-10A
 TS 940 - requires Kenwood IF-10B
 TS 440 - requires Kenwood IC-10