

Upgrading from Router 4.0.x to 5.x

To install Router 5 to a system with a previous version of Router:

- 1) Backup your presets (Router | Backup Router Settings)
- 2) Delete all Virtual Ports (Virtual Port | Delete All)
- 3) Close Router (Router | Exit)
- 4) Unplug the USB cable from your interface
- 5) Download the new Router from:
www.microham.com/Downloads/urouter_release_05_01_01.exe
- 6) Run the downloaded Router file - it will uninstall any previous version of Router and restart your computer before installing the upgrade.
- 7) Connect the USB cable to the interface
- 8) Manually upload the new firmware file (Device | Upload Firmware) if Router does not prompt you to do so (not applicable to USB Interface II)..
- 9) Reload your presets (Router | Restore Router Settings)
- 10) Reselect your radio (*microKEYER*, *microKEYER II*, MK2R/MK2R+ only)
- 11) Adjust/modify your presets as needed to adjust for the changes in Router 5 and save the updated presets.
- 12) Save your new "Power-up" settings (Device | Store as Power-up Settings)
(not applicable with USB Interface II)
- 13) Update your "Router Back-up" (Router | Backup Router Settings)
- 14) Have fun exploring Router 5!